

# Moulded Cords & Cables Ltd. Information Library.

## How to Wire a IEC320 C13 Socket. (STK153)



© MCC Ltd 2010



**ELECTRICITY CAN KILL!**  
If you are in any doubt at all about what you are doing,  
or your ability to do the work, you should refer any  
mains connection work to a qualified electrician.

### Wiring up a IEC320 C13 IEC Socket.

1. Unscrew the outer case and remove, unscrew cable clamp and unscrew required terminal.
2. Place the Strain relief on the cable.
3. Strip the cable according to Figure 1.
4. Connect the cable to the correct terminals and fasten screws to hold in place.
5. Place the Strain Relief inside the body.
6. Screw Cable clamp over the cable making sure its clamped over the cable outer.
7. Replace IEC Lid and fasten screw till tight.

Figure 1.

