

Moulded Cords & Cables Ltd. Information Library.

How to Wire an Italian 10A Plug. (STK6)



Wiring up an Italian Plug.

© MCC Ltd 2012

ELECTRICITY CAN KILL!
If you are in any doubt at all about what you are doing,
or your ability to do the work, you should refer any
mains connection work to a qualified electrician.



1. Unscrew the outer case and remove, unscrew cable clamp and unscrew required terminal.
2. Strip the cable outer sheath back 30mm, inner 5mm.
3. Connect the cable to the correct terminals and fasten screws to hold in place.
4. Screw Cable clamp over the cable making sure its clamped over the cable outer.
5. Replace Lid and fasten screw till tight.

